



X8.1 Sirius

LMAX X8.1 Sirius firmware update tutorial

Note - Camera must be connected to the charger by Micro USB cable during the entire update process to avoid interruption of the update due to the lack of battery power. Disrupting the update before it is completed can damage the camera permanently.

1. Format the Micro SD card and make sure it is empty.
2. Upload the file "FW96660A.bin" directly to the Micro SD card. (Do not create any folder but upload the file directly to the card.)
3. Insert the card with the uploaded file into the turned off camera.
4. Turn on the camera with the "On/Off" button.
5. Firmware begins to update, even though camera looks as it is turned off. Do not push the buttons or take the battery out of the camera.
6. When the update is completed, the camera turns on, including the LCD screen. (The update lasts approximately up to 1 minute.)
7. Turn off the camera and remove the Micro SD card.
8. Turn on the camera.
9. In the camera menu, go to the "Firmware" section and check if the firmware is updated to version „20171222“.